

NSCOMMANDER - Commander LED Flashlight

User Manual

Before using your NightSearcher Flashlight, Please read this user manual, it contains important safety information and operating instructions.

• Technical Specification:

Light output: 700 lumen

Running time: 1.6 / 120 hours

Charge time: 2 hours

Battery: 1x 18650 Lithium

Light source: 4 chip Cree® MC-E LED

Product size: Head Diameter: 40mm / Length: 150mm

Product weight: 185g (with batteries)

Part No. NSCOMMANDER

Supplied with: Wrist strap, x2 Batteries, Mains and Vehicle chargers

• LED Assembly Replacement

The Light Emitting Diodes (LED) can last 50,000hrs+ and seldom need replacing. If there is any malfunction of LED, please contact NightSearcher Limited or an authorised distributor.

• Battery Replacement

Unscrew the tailcap and insert batteries and screw the tailcap to tighten it. Press the tailcap push button to test.

Note: In order to protect the flashlight, please put the batteries anode (+) side toward the torch head. Reverse polarity may damage the circuit.

• Battery Charging

- Always insert the battery into the charger according to the positive (+) and negative (-) mark, if not inserted correctly, both the charger and the battery will be damaged. When the power is on, the red LED lights up, showing that the battery is charging; The green LED will turn on when the battery is full.
- This charger has a built-in protection system, long time charging will not cause battery overload. These batteries can be charged at any time without causing "memory affect" or damage to the battery. However, less than 8 hours continuous charging is suggested for safety.

Warning: Lithium batteries can explode or cause burns if disassembled, short circuited or exposed to fire/high temperature. Do not expose the contents to water or mix with other types of batteries.



Due to heat, never use this charger in explosive places (such as gas stations). Avoid using in hot surroundings (over 60°) or placing the charger on textiles or foams.

• ON and OFF & 6 Mode Operation

The ON-OFF switch is located in tail of the flashlight, press the switch fully and the flashlight will turn on; press the switch halfway in order to operate the different modes. The Commander has 6 light functions: High, Medium, Low, Flashing, Strobe and SOS. At any mode to turn the torch off, press the switch fully.

• Flashlight Maintenance

- Use a small brush or blow dry air to clean the dust inside the reflector.
- To remove any fingerprints on the lens, use a lens cleaner and cotton swab.
- To prevent the O-ring from drying and threads operating smoothly, apply petroleum jelly to these surfaces 2-3 times a year (O-ring prevents water from getting into the flashlight).
- Do not use flashlight for diving, it is not suitable for high pressure underwater environment.
- If water gets inside the flashlight, remove the battery immediately and dry, or put the battery in an area with good ventilation.
- The non-anodized metal groove between the tail cap and the barrel must be cleaned periodically to ensure a good electrical contact.
- Always keep the tail cap spring clean.

• NightSearcher Guarantee

NightSearcher products have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship for a period of 12 months from the date of purchase, provided that the enclosed instructions have been followed.

Should you experience problems with your product, please return the complete item (inc. charger) to your purchase stockist or contact NightSearcher (address printed below).

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out FOC. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted by any personnel without prior approval from NightSearcher Ltd.

Your NightSearcher guarantee is not effective unless you can produce a dated receipt of purchase.

This guarantee does not affect your statutory rights.

• Safe disposal of waste electrical products, batteries and bulbs



If need to dispose of this product or parts of this product: Please note that waste electrical products, batteries and bulbs should not be disposed of with household waste. Please recycle where facilities exist, please check with your local authority for recycling advice.

NightSearcher Limited

Unit 4 Applied House, Fitzherbert Spur, Farlington, Portsmouth, Hampshire, PO6 1TT, UK.

Tel: +44 (0)23 9238 9774 Fax: +44 (0)23 9238 9788

Web: www.nightsearcher.co.uk

Email: sales@nightsearcher.co.uk